

Cleaning & Care

Tablet & Ticket products are manufactured to be easily cleaned and disinfected. Surfaces and materials are specifically chosen to adhere to BIFMA's guidelines for performance as it relates to typical cleaners, disinfectants, and methods for cleaning and maintenance.

Case Backs:

Tackable Cork Care: Treat spots and stains using a damp, clean cloth with a mild solution of liquid detergent and warm water. Vinegar can be added for additional cleaning. Pat dry with a lint free cloth.

Tackable Fabric Care: Surface can be maintained with regular vacuuming using a dusting attachment. Treat spots and stains using a damp, clean cloth with a mild solution of liquid detergent and warm water. Do not saturate the surface. Avoid scrubbing motion to prevent pilling. Pat dry with a lint free cloth. Allow to completely dry before using.

Tackable Vinyl/Recycled Rubber Care: Treat spots and stains using a damp, clean cloth with a mild solution of liquid detergent and warm water. Vinegar can be added for additional cleaning. Pat dry with a lint free cloth. Allow to completely dry before using.

Tackable Hygienic Forbo Care: Surface can be maintained with regular dusting or by wiping clean with a white damp cloth. For more stubborn marks, gently clean the surface using a soft bristle brush and lukewarm water with neutral pH detergent. Remove cleaning solution with a squeegee and cloth. Rinse with clean water and remove any remaining water with a squeegee and cloth.

Laminate & Framing:

Use a clean, damp, nonabrasive cotton cloth and mild liquid detergent or household cleaner. Rinse with clean water, using a non-abrasive cotton cloth. Dry surface with a non-abrasive cotton cloth.

Glass Shelves:

Clear shelves. Use a soft-bristled brush or dry microfiber cloth to clear away loose dust. Spray a neutral pH glass cleaner on microfiber cloth to prevent liquid from pooling in the frame corners. Wipe in overlapping, straight lines. Fold microfiber cloth into a sharp point to clean tight corners. Use a dry microfiber cloth to buff the glass.

Glass Door Fronts:

Use a soft-bristled brush or dry microfiber cloth to clear away loose dust. Spray a neutral pH glass cleaner on microfiber cloth to prevent liquid from pooling in the frame corners. Wipe in overlapping, straight lines. Fold microfiber cloth into a sharp point to clean tight corners. Use a dry microfiber cloth to buff the glass.